


MODEL : TUK50



SPARE PARTS LIST

NO:MP-1910

REF. NO.	DESCRIPTION	PART NO.	QTY.	REF. NO.	DESCRIPTION	PART NO.	QTY.
1	Cylinder head	3101048	2	32	Inlet/Exhaust washer	2B31-001	4
2	Allen bolt set	3B01-M10*055V	8	33	Inlet valve assembly	3B12-PU23	2
3	Exhaust tube set	3B2-06*220	1	34	Unloading piston	2113009	2
4	Air filter set	2140009	2	35	O-ring	3B2-02*475C	2
5	Filter element	2142002	2	36	Inlet valve holder	3110008	2
6	Cylinder head gasket	2G01-007C	2	37	Unloading elbow	2N16-C01TW02M	1
7	Double head bolt set	3B11-003-A	12	38	Unloading tube set	3B2-02*475C	2
8	Cylinder	3201015	2	39	Hexagon bolt set	3B00-SM08*030V	8
9	Cylinder gasket	2G04-009	3	40	Exhaust press plate	3126004	2
10	Piston ring set	3B32-80N	2	41	O-Ring	2N52-G45V	2
11	Piston set	3B31-80L	2	42	Exhaust valve assembly	3B11-NPP23	2
12	Rod set	3B33-P2346	1	43	Unloading 3-way pipe	2N17-CW0201TW2M	2
13	Rod bush	2316001-B	3	44	Rod set	3B33-P2337	1
14	Crankcase	3301127	1	45	Exhaust 3-way pipe	2N09-06H06T06H2	1
15	Oil draining plug	2N33-002	1	46	Cylinder head	3101056	1
16	Oil sight gauge set	2303016A	1	47	Allen bolt set	3B01-M06*040V	4
17	Oil filling plug set	2319004B	1	48	In. & Ex. valve assembly set	3B13-AC0765C	1
18	Bearing	2N35-6306	2	49	Cylinder	3201029	1
19	Crankshaft & balancer	3304025	1	50	Piston ring set	3B32-65N	1
20	Pulley key	2N47-63*09	1	51	Piston set	3B31-T65	1
21	Rear bearing seat	2G06-002	1	52	Rod set	3B33-T5048	1
22	Oil mesh	2352002	1	53	Exhaust elbow	2N06-06T06T85	1
23	Rear bearing seat	3311003	1	54	Spare tank	3125001	1
24	Hexagon bolt	2B00-SM10*025	6	55	Pressure relief valve	2406020A	1
25	Breathing cover	2321008	1	56	Unloading spring	2S03-001	1
26	Oil seal	2N50-TC30*50*11	1	57	O-ring	2N52-P06V	1
27	Pulley	3PBF-145A230M	1	58	Unloading piston	2113015	1
28	Pulley washer	2B34-13*52*14	1	59	O-ring	2N52-P16*3V	1
29	Hexagon bolt set	3B00-SM12*050V	1	60	Unloading nut	2B26-003	1
30	Exhaust elbow	2N06-06T06H	3	61	O-ring	2N52-P09V	1
31	Exhaust tube set	3B2-06*490	1				